

# **DSCL24 (Single Channel)**

## Jumper Configurable - DIN or Panel Mount

## DIN Rei

### **Description**

Each single channel DSCL24 module provides up to 36 different configurations of process current or voltage inputs and outputs. A unique snap-in tool allows quick extraction of the module's circuit board to permit the user to reposition four (4) jumpers and reconfigure each module's I/O. The factory default setting provides 4-20mA input and output current.

Each module provides full 3-way isolation with 2300Vrms CMV input to output and 3700Vrms CMV power supply to I/O protection. Two module versions are offered that accept universal power supply of either 24 to 60VDC or AC and 85 to 230VDC or AC with the alternating current usage accepting 45 to 400Hz power.

#### ▶ Features

- Uses Universal Power Supply of 24 to 60V or 85 to 230V AC/DC
- Configuration Jumpers Allows up to 36 I/O Settings
- Three-Way Isolation for 2300Vrms Protection
- · Prevents Ground-Loop Problems
- Prevents the Transfer of Interference Voltages and Currents
- · High Accuracy Over Full Span
- · No Recalibration or Maintenance Required
- Narrow DIN Package, Mounts up to 27 Devices into a 19" Rack Space
- · DIN Rail or Panel Mountable
- CE Compliant




Figure 1: DSCL24 Block Diagram



## $\textbf{Specifications} \ \ \text{Typical at T}_{\text{\tiny A}} = +25^{\circ}\text{C and 24VDC or 230VAC} \pm 10\% \ \text{supply voltage}$

Module	DSCL24-01,-02
Input Range <sup>(1)</sup> Input Limit (I <sub>in</sub> ) Input Limit (V <sub>in</sub> ) Input Limit (V <sub>in</sub> ) CMV Input to Output CMV Power Supply to I/O Accuracy (at 250Ω Load) Input Resistance Non-linearity Stability Input Overshoot	0/4-20mA, ±20mA, 2-10V, 0-10V, ±10V 50mA, ±50mA 40V, ±40V 2300Vrms, 1 min. 3700Vrms, 1 min. ±0.1% Span Typical ±0.2% Span Max 15Ω Current Mode, 100kΩ Voltage Mode Included in Accuracy <100ppm/°C <20μA (Typical 5μA)
Output Range <sup>(1)</sup> Output Limit (I <sub>out</sub> ) Output Limit (V <sub>out</sub> ) Limit Upper Range Bandwidth, -3dB CMR (50Hz or 60Hz) NMR Response Time Load Resistance Range Output Noise	0/4-20mA, ±20mA, 2-10V, 0-10V, ±10V 20mA, ±20mA 10V, ±10V 40mA 15Hz 110dB 16dB at 50/60 Hz 30ms, to 90% Span ≤600Ω Current Mode, ≥2kΩ Voltage Mode <0.5% p-p
Power Supply Voltage Tolerance Power consumption	(24 to 60) or (85 to 230)VDC/AC at 45-400Hz DC −15% to +33%, AC ±15% DC ≤1.2W, AC ≤3VA
Environmental Housing Material Shock Test Operating Temp Range Storage Temp Range Relative Humidity Emissions Immunity	Weight Approximately 180g Lexan 940 (UL 94 V-O) 50g (3 Shocks, 6 Axis) -25°C to +55°C -40°C to +70°C 0 to 75% Noncondensing EN50081-2 (Radiated, Conducted) EN50082-2 (ESD, RF, EFT)

#### NOTES:

## **Configuration Guide**

The default setting of factory stock modules is 0 to 20mA for both module input and output, that is, jumpers are inserted in positions B2 and B5 designating 0-20mA input and jumpers ST4 and ST3 are in position for 0 to 20mA current output.

However, the output can be user reconfigured for an alternative voltage or current signal by inserting the plug-in jumpers ST4 and ST3 in the appropriate positions shown in table 1.

## **Ordering Information**

Model	Input (default(1))	Output (default(1))	Power Supply	
DSCL24-01	4-20mA	4-20mA	24-60VDC/AC	
DSCL24-02	4-20mA	4-20mA	85-230VDC/AC	

Table 1: Select Output Voltage or Current


Output →	Jum	Jumpers		
	ST 4	ST 3		
Voltage [V]	U	U 1		
Current [mA]	<b>- (1-4.1)</b> U I	<b>- (1)</b>		

Table 2: Select Voltage or Current Ranges

<b>→</b>	420 mA	020 mA	–20…20 mA	210 V	010 V	–10…10 V
420 mA	B1, B4	B2, B4	B3, B4	B1, B4	B2, B4	B3, B4
020 mA	B1, B5	B2, B5	B3, B5	B1, B5	B2, B5	B3, B5
-2020 mA	B1, B6	B2, B6	B3, B6	B1, B6	B2, B6	B3, B6
210 V	B1, B4	B2, B4	B3, B4	B1, B4	B2, B4	B3, B4
010 V	B1, B5	B2, B5	B3, B5	B1, B5	B2, B5	B3, B5
–1010 V	B1, B6	B2, B6	B3, B6	B1, B6	B2, B6	B3, B6


NOTE: B1 through B6 Jumpers marked on PC board

<sup>(1)</sup> Thirty-six unique I/O ranges are jumper configurable. See Tables 1 & 2 for configuration options.



Jumpers B1 to B6 (table 2) are used for selecting the standard configurable ranges. Providing that the 'Span' and 'Zero' potentiometers are not adjusted, changing the range has no effect on the modules' accuracy. The 'Span' and 'Zero' allow ±10% adjustments.

### **Dimensions**



## **Connection Guide**

